ASSEMBLY INSTRUCTIONS

Tools Required: Philips Screwdriver



Step 1: Axle Tube & Wheel Shaft Assembly

- 1. Connect both side tubes and wheel shafts to axle tube through axle fittings. Make sure the Dynamic label faces aft.
- 2. Connect sling to side tubes through sling fittings.





Step 2: Tongue & Bow Tube Assembly

- 1. Slide aft tongue tube over splice tube, which is riveted into the forward tongue tube, until snap button is engaged.
- 2. Slide V-fitting over forward tongue tube and secure in place with a hex head bolt and wing



- 4. Slide V-fitting over bow tube and secure in place with hex head bolt and wing nut.
- 5. Attach handle fitting to bow tube.
- 6. Slide handle tube through handle fitting until centered. With the palm of your hand, gently tap both handle grips onto handle tube from both ends.





Tongue

Tube

Step 3: Final Assembly

- 1. Connect axle tube to tongue tube assembly with the cross fitting. Make sure Dynamic label on axle tube faces aft.
- 2. For a quick dolly-breakdown, use hex head bolts and wing nuts as shown in picture.
- 3. Slide wheels onto wheel shafts while depressing snap button.
- 4. Wheels can be secured on the dolly by inserting the enclosed short flat head machine screws under the snap buttons.
- 5. Tire pressure not to exceed 15 psi. For soft sand conditions, reduce tire pressure to increase tire footprint.
- 6. Wheels are not for highway use.

Contact us:

401-683-0427, 275 High Point Ave, Portsmouth RI 02871 Info@dynamicdollies.com

www.dynamicdollies.com



Wing Nuts for Quick Disconnect



Unsecured Snap Button



Snap Button Immobilized



Type 7 Dolly

