


ASSEMBLY INSTRUCTIONS

Tools Required: Philips Screwdriver


Step 1: Tongue & Bow Tube Assembly

1. Slide aft tongue tube over splice tube, which is riveted into the forward tongue tube, until snap button is engaged.
2. Attach both cross fittings to tongue tube.
3. Connect bow tube to forward tongue tube through elbow fitting. Make sure the Dynamic address label on the bow tube faces aft.
4. Attach handle fitting to bow tube.
5. Slide handle tube through handle fitting until centered. With the palm of your hand, gently tap both handle grips onto handle tube from both ends.



Step 2: Axle Tube Assembly

1. Connect round side tubes to axle tube.
2. Connect wheel shafts to axle tube through axle fittings.



Step 3: Cross Tube Assembly

Connect round side tubes to cross tube. Make sure Dynamic label on cross tube faces forward.

Step 4: Final Assembly

1. Connect axle tube to tongue tube assembly through the aft cross fitting. Make sure Dynamic label on axle tube faces aft.
2. Connect forward cross tube to tongue tube.
3. For a quick dolly-breakdown, use hex head bolts and wing nuts as shown in picture.
4. Slide wheels onto wheel shafts while depressing snap button.
5. Wheels can be secured on the dolly by inserting the enclosed short flat head machine screws under the snap buttons.
6. Tire pressure not to exceed 15 psi. For soft sand conditions, reduce tire pressure to increase tire footprint.



Wing Nuts for Quick Disconnect

Contact us:

401-683-0427, 275 High Point Ave, Portsmouth RI 02871
info@dynamicdollies.com

www.dynamicdollies.com



Unsecured Snap Button



Snap Button Immobilized



Type 10 Dolly

